



CARING FOR YOUR BLOCKOUT BLINDS

To ensure that your new Blockout Blinds remain beautiful and functional for years to come, we encourage you to carefully read through this guide.

Inside, you'll find essential tips on both operation and maintenance.

CLEANING

Regular dusting with a feather duster or soft cloth is all that's required to keep your blackout blinds fabric looking good.

For the removal of stains, dirt and grime, gently wipe fabric with a damp wrung sponge soaked in lukewarm water. If there are still visible marks, a small amount of detergent can be added, then dried gently with a clean cloth.

Test in an inconspicuous area before spot cleaning to ensure detergent does not further stain the fabric.

Do not use harsh chemicals on your blinds, as this will damage the fabric permanently.

The blind tracks can be cleaned with warm soapy water if required.

Ensure your blind is left down until fully dry.

MOTORS

It is recommended your blind motor is charged every 3 months if getting used once a day. This will increase the longevity of your motor and battery.

The motor can be charged with a USB-C charging cable.

GENERAL MAINTENANCE

Just Quality recommends to keep your windows closed if the blind is down, as strong gusts of wind may dislodge the blind from the tracks.

REMOTES

To operate your motorised Blockout Blinds, simply press the arrows on the remote to control the direction the blind moves. At any point while the blind is moving, the middle button can be pressed to stop the operation.

How to hide / show / unlock channels on your Blockout Blind Remote:

1. Press briefly (very quick push) the setting button found on the side of the remote control. The channel number will start to flash.
2. Use the left/right selection buttons to scroll through the channels from 1 to 16.
3. Go to the channel that you wish to hide or show.
4. Press the STOP (middle) button to show or hide a channel, you will notice the channel number will either flash rapidly to indicate that the channel is now hidden or it will flash slowly to indicate that it is now visible.
5. Press briefly (very quick push) the setting button found on the side of the remote control to exit the setting mode.





Thank you for choosing Just Quality! We hope you enjoy your Blockout Blinds for years to come.

For any further questions, please contact us on 1300 813 813.

1300 813 813
info@justquality.com.au
justquality.com.au

11/43 Port Road
Thebarton, SA 5031



Outdoor Blinds | Blockout Blinds | Roller Shutters
Plantation Shutters | Artificial Turf | Paving
Roof Restorations | Re-roofing | Guttering | Garage Doors